



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

**REV. 00**

[www.cobra.it](http://www.cobra.it)

MAKE	<b>TOYOTA</b>	MOD.	<b>AVENSIS</b>	YEAR	<b>03</b> →	PETROL <input checked="" type="checkbox"/>	DIESEL <input type="checkbox"/>
------	---------------	------	----------------	------	-------------	--	---------------------------------

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens on the support of the shock absorber, passenger's side.
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the dashboard, driver's side.
<b>POWER SUPPLY</b>	<b>+30:</b> connect to the WHITE wire, in the second free slot of the fuse box. Add a 25Amp fuse. <b>-31:</b> connect to a ground terminal located behind the left lateral bulkhead, driver's side.
<b>IGNITION WIRE</b>	<b>+15/54:</b> connect to the BLACK/RED wire, in the light blue connector located behind the fuse box.
<b>DIRECTION INDICATORS</b>	Connect to the GREEN/WHITE and GREEN/YELLOW wires in the black connector of the direction indicators grey relay located behind the fuse box.
<b>ELECTRIC WINDOWS</b>	<p><b>Positive control signal</b></p> <p><b>Front window, driver's side:</b> cut the GREEN wire in the connector directly coming out of the driver's side window motor.</p> <p><b>Front window, passenger's side:</b> cut the GREEN/WHITE wire, at the position nr.13, in the 13 way white connector, behind the driver's side bulkhead.</p> <p><b>Rear window, driver's side:</b> cut the GREEN/BLACK wire, at the position nr.9, in the 13 way white connector, behind the driver's side bulkhead.</p> <p><b>Rear window, passenger's side:</b> cut the GREEN/YELLOW wire, at the position nr.11, in the 13 way white connector, behind the driver's side bulkhead.</p>
<b>CENTRAL DOORS LOCKING</b>	<p><b>Negative control signal</b></p> <p>Connect to the BROWN/WHITE wire (lock) and to the GREEN/WHITE wire (unlock), in the 24 way white connector behind the driver's side sill cover.</p>
<b>IMMOBILISATION POINT</b>	<p><b>Fuel pump</b></p> <p>Cut the GREEN/YELLOW wire, at the position nr.6, in the 10 way connector located behind the driver's side sill cover.</p>
<b>STARTER</b>	<b>+50:</b> Cut the BLACK wire coming out of the 10 way white connector, located behind the passenger's side glove compartment.
<b>BONNET SWITCH</b>	Install an additional switch on the headlamp support plate, driver's side.
<b>DOORS SWITCH</b>	Connect to the RED wire, at the position nr.4 in the driver's side door, and to the WHITE/GREEN wire, at the position nr. 14 in the rear doors, in the 18 way white connector, behind the driver's side sill cover; connect to the RED wire at the position nr.9, in the passenger side door, in the grey connector on the fuse box.
<b>BOOT SWITCH</b>	Connect to the RED/YELLOW wire in the wiring harness located in the sill cover of the driver's side door.