



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

TOYOTA

MOD.

RAV 4

YEAR

02 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the driver's side wheel house using the original rubber core hitch.

CENTRAL UNIT POSITION

Install the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+30: connect to the 4 mm² BLACK/RED wire located in the fuse box.
- 31: connect to an original ground terminal.

IGNITION WIRE

+15/54: connect to the RED/BLUE wire in the 8 way white connector, on the right of the fuse box.

DIRECTION INDICATORS

Connect to the GREEN/YELLOW wire at the position nr. 8 and to the GREEN/BLACK wire at the position nr. 4, in the 32 way white connector, in the fuse box.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the YELLOW wire, at the position nr. 4, on the 18 way connector of the push-button panel, in the driver's side door.

Front window, passenger's side:

cut the GREEN/RED wire, at the position nr.3, in the 13 way connector, behind the driver's side sill cover.

Rear window, driver's side:

cut the BLUE/BLACK wire, at the position nr.12, in the 13 way white connector, behind the driver's side sill cover.

Rear window, passenger's side:

cut the RED/YELLOW wire, at the position nr. 10, in the 13 way white connector behind the driver's side sill cover.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the BLUE/ORANGE wire at the position nr.6 (lock) and to the BLUE/YELLOW wire at the position nr.13 (unlock) located in the 14 way connector, behind the driver's side sill cover.

IMMOBILISATION POINT

Fuel pump

Cut the 1,5 mm² BLUE/BLACK wire located in the 16 way white connector with black hook, in the driver's side sill cover.

STARTER

+50: Cut the 2,5 mm² RED wire located in the wiring harness coming out of the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate, driver's side.

DOORS AND BOOT SWITCH

connect to the RED/BLACK wire, at the position nr. 1, in the 10 way connector, on the central unit placed behind the passenger's side glove compartment.