



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

TOYOTA

MOD.

YARIS

YEAR

99 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side. Pass the cables through the original rubber sleeve located in the bulkhead that divides the engine compartment from the passenger's compartment, driver's side.

CENTRAL UNIT POSITION

Position the modular system and the modules under the dashboard, driver's side.

POWER SUPPLY

+ **30**: connect to the 3 mm² RED/WHITE wire located in a multiway connector at the entrance of the fuse box.
- **31**: connect with a terminal directly to the car body.

IGNITION WIRE

+ **15/54**: connect to the 1,5 mm² BLUE wire located in the wiring harness of the 13 way white connector behind the left lateral bulkhead, driver's side.

DIRECTION INDICATORS

Connect to the 1,5 mm² GREEN/BLACK wires with GREY references and GREEN/YELLOW with GREY references located in the bundle of cables behind the sill cover, driver's side.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the 1,5 mm² RED wire located in the 10 way white connector linked to the window switch, inside the driver's side door.

Front window, passenger's side:

cut the 1,5 mm² BLUE/RED wire located in the 13 way white connector behind the sill cover, driver's side.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the 0,75 mm² GREEN/BLACK wire with GREY references (unlock) and BLACK/RED wire with GREY references (lock) located respectively at the positions nr.13 and nr.12 in the 14 way white connector located behind the sill cover, driver's side.

IMMOBILISATION POINT 1

Fuel pump

Cut the 1 mm² BLACK/RED wire with GREY references located in the wiring harness behind the sill cover, driver's side.

IMMOBILISATION POINT 2

Starter

Cut the 0,75 mm² BLACK wire with GREY references located in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate, near the headlamp, driver's side.

DOORS SWITCH

Connect to the 0,75 mm² RED/YELLOW wire with GREY references located in the 25 way white connector linked to the central doors locking unit (light blue color) located to the left of the switchboard.

BOOT SWITCH

Install an additional push button.