



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

**TOYOTA**

MOD.

**YARIS**

YEAR.

**01** →

PETROL   
DIESEL

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side. Pass the cables through the original rubber sleeve located in the bulkhead that divides the engine compartment from the passenger's compartment, driver's side.

#### CENTRAL UNIT POSITION

Position the modular system and the modules under the dashboard, driver's side.

#### POWER SUPPLY

**+ 30:** connect to the 3 mm<sup>2</sup> RED/WHITE wire located in a multiway connector at the entrance of the fuse box.  
**- 31:** connect with a terminal directly to the car body.

#### IGNITION WIRE

**+ 15/54:** connect to the 1,5 mm<sup>2</sup> BLUE wire located in the wiring harness of the 13 way white connector behind the left lateral bulkhead, driver's side.

#### DIRECTION INDICATORS

Connect to the 1,5 mm<sup>2</sup> GREEN/BLACK wire with GREY references and to the GREEN/YELLOW wire with GREY references located in the bundle of cables behind the sill cover, driver's side.

#### ELECTRIC WINDOWS

##### Positive control signal

##### Front window, driver's side:

cut the 1,5 mm<sup>2</sup> RED wire located in the 10 way white connector linked to the window switch, inside the driver's side door.

##### Front window, passenger's side:

cut the 1,5 mm<sup>2</sup> BLUE/RED wire located in the 13 way white connector behind the sill cover, driver's side.

#### CENTRAL DOORS LOCKING

##### Negative control signal

Connect to the BROWN/YELLOW wire (lock) and to the GREEN/BLACK wire (unlock) located in the multiway connector, behind the switchboard.

#### IMMOBILISATION POINT

##### Fuel pump

Cut the 1 mm<sup>2</sup> BLACK/RED wire with GREY references located in the wiring harness behind the sill cover, driver's side.

#### STARTER

**+50:** Cut the 0,75 mm<sup>2</sup> BLACK wire with GREY references located in the wiring harness coming out of the connector of the ignition key.

#### BONNET SWITCH

Install an additional switch on the headlamp support plate, near the headlamp, driver's side.

#### DOORS SWITCH

Connect to the 0,75 mm<sup>2</sup> RED/YELLOW wire with GREY references located in the 25 way white connector linked to the central doors locking unit (light blue color) located to the left of the switchboard.

#### BOOT SWITCH

Install an additional switch.