## SHEET N.: 44-7 / G8

## VEHICLE: TOYOTA MR 2

ALARM POSITIONING

Compact units and sirens Control units and modules

## **WIRING LOCATION**

## EARTH CONNECTION

Positive and Negative

 $\Rightarrow$  to the battery terminals.

- Year of introduction 1996

FUNCTION AND MODALITY OF THE CONNECTION	VEHICLES WIRE COLOUR	WIRE POSITIONING
DIRECTION INDICATOR LIGHTS:	GREEN-YELLOWref.GREY0,75mmsqgreen-blackref.GREY0,75mmsqgreen-blackgreen-blackgreen-black	Connector: 34-pin BLACK connected to the fuse box.
	BLACK-ORANGE ref. GREY 0,75 mmsq	Connected to the FUEL PUMP relay in the engine compartment – driver's side.
<u>1° ENGINE IMMOBILISATION</u> : (starter motor) ➤ Use A 30 Amp. Gemini 2352 relay.	BLACK-WHITE 2,5 mmsq	Connected to the the ignition switch.
2° ENGINE IMMOBILISATION: (FUEL PUMP - PETROL VEHICLES) ≫	BLACK-ORANGE ref. GREY 0,75 mmsq	Connected to the FUEL PUMP relay in the engine compartment – driver's side.
CENTRAL DOOR LOCKING: - diagram N. 2 – common negative.	<u>To open:</u> GREEN-BLACK ref. GREY 0,75 mmsq <u>To close:</u> RED-BLACK ref. GREY 0,75 mmsq	<u>Connector</u> : 18-pin WHITE connected to the closure unit on the left side of the steering column.
ELECTRIC WINDOWS: use a module 2244	<u>Front:</u> a. + ↑ L.h.s.: GREEN 1,5 mmsq b. + ↑ R.h.s.: GREEN-BROWN 1,5 mmsq	a. Connected to the control switches inside the driver's door. b. Driver's door harness.
	RED-WHITE ref. GREY 1 mmsq	Connector: 16-pin WHITE positioned in the connectors group behind the driver's kick plate.
<b>BONNET PIN SWITCH:</b> Install the button supplied with the kit on the passenger's light.		
BOOT PIN SWITCHES:	RED-WHITE ref. GREY 0,75 mmsq	Connected to the boot light.

VEHICLE KEY FOR RADIO KEY TRANSMITTER: Blade Kit RK N. 39

NOTE: the voltage sensing circuit can be isolated

N.B. THE ABOVE MENTIONED INFORMATIONS ARE ONLY INDICA TIVE. THE MANUFACTURER RESERVES THE RIGHTS TO EXECUTE MODIFICATION WITHOUT PRIOR NOTICE.



- ⇒ On the shock absorber turret on the passenger's side.
  ⇒ Behind the passenger's foot rest.
- - $\Rightarrow$  Use the original harness on the passenger's side.